

KITCHEN DOOR CARE INSTRUCTIONS

Before commencing any work on doors or accessories, please examine the product thoroughly, ensuring it meets your requirements for colour consistency and is scratch or blemish free.

Once the product has been altered in any way from the condition it was supplied, it **cannot** be replaced.

Fitting care

Always handle products with care to avoid damage.

Take care when fitting hinges & handles, ensure doors/drawers are placed on a clean and padded surface to avoid damages such as scratches.

Timber, veneered & hand painted doors

Timber is a natural product, therefore colour, grain structure and features will vary between doors/drawers. Untreated doors must be treated before use.

Timber, veneered & hand painted doors may change over time when exposed to sunlight. Please be aware of this natural colour change when ordering additional doors to match a previous install.

We also recommend all timber/painted samples should be updated over time because of this reason.

These doors are also affected by moisture, humid environments can have adverse effects on doors over a period of time. Please check the moisture content of a room before installing doors.



PARAPAN
HIGH GLOSS SOLID ACRYLIC

Landau House, Bontoft Avenue, Hull HU5 4HF
www.landau.uk.com
Tel: 01482 440680
Email: sales@landau.uk.com

Cleaning

We recommend the following cleaning instructions for **timber, veneered & painted doors**:

- Use a solution of 95% luke warm water with a maximum of 5% soap.
- Use a clean damp (not wet) cloth gently. Dry with a soft clean cloth.
- If it is a timber door run the cloth along the grain direction.
- Any cooking marks must be wiped immediately.
- Do not allow liquids to seep into joints.
- All spillages must be wiped immediately.

We recommend the following cleaning instructions for **Parapan**[®]:

- Dusty parts can be wiped down with water, a soft cloth or sponge.
- Never rub when dry.
- For thorough cleaning we recommend Parastat[®] (this is an intensive acrylic cleaner that prevents static charging thus preventing the attraction of new dust).
- Apply the Parastat to a microfiber cloth and clean the surface in a criss-cross movement.
- Allow the film which develops on the surface to dry (Do not rub dry).
- Parapan can then be polished with a soft smooth cloth which will leave the surface shining brilliantly.

Environmental information

Newly plastered rooms & plaster repair should be left to dry before installation.

Please be aware localised or intense heat/ steam can damage fascias. Subsequently the use of small appliances such as kettles or toasters in close proximity to kitchen fascias should be avoided.